

MATT EMULSION EASY CLEAN BREATHEASY®

Crown Easyclean matt emulsion is specially formulated to allow for repetitive cleaning and is 200 times tougher and more washable than our standard matt paint. Easyclean has been independently tested and is shown to be the best for stain and scrub resistance, toughness and washability. Easyclean keeps walls, ceilings, wood and metal looking cleaner for longer, making it perfect for busy family homes.

AVAILABILITY

Colour Range Available in popular Crown Colors plus Pure Brilliant White

Packaging 2.5 L

PROPERTIES

Drying Time Under normal drying conditions touch dry in 2 hours, recoatable after 4 hours. Allow for adequate ventilation during the drying period.

Finish Matt

Composition Pigment: Titanium Dioxide and inorganic extenders.
Binder: Vinyl acetate copolymer.
Solvent: Water.

Spreading Rate For 14m² per litre on smooth surfaces.

Interior or exterior Interior

Washable & Wipeable Yes

Suitable for Walls, Ceiling, Woods and Metals

Flash Point Not applicable.

VOC Content Low

Limitations For interior use only. Do not apply when air or substrate temperatures are likely to fall below 10°C or when the relative humidity is above 80% during application or the drying period.

PREPARATION

New Surfaces All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Powdery, polished plaster or dense surfaces should be primed with Crown Trade Alkali Resisting Sealer. Porous surfaces should be 'mist' coated with Crown Easy Clean Matt Emulsion Breatheasy® thinned with up to 40% clean water.

Previously decorated surfaces All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied e.g. dirt, grease etc. Remove all loose, failing or suspect paint. Feather edges of sound paint. Remove all dust. Organic growth must be removed and the areas treated with Crown Trade Fungicidal Solution. Fill any fixing holes, cracks and shallow surface defects using a suitable proprietary interior filler. Patch prime bare and filled areas with Crown Easy Clean Matt Emulsion Breatheasy®. Wash remaining sound paint with hot water and liquid detergent solution to remove any contaminants, frequently changing the water. Any glossy or eggshell surfaces should be wet abraded to provide a key. Rinse with clean water to remove all residues. Allow to dry. If after cleaning any areas still contaminated with substances likely to cause staining and/or bleeding, patch prime with one coat of Crown Stain Block Primer. Bring forward patch primed areas with one coat of Crown Easy Clean Matt Emulsion Breatheasy®.

COATING SYSTEM

Apply two full coats of Crown Easy Clean Matt Emulsion Breatheasy®.

APPLICATION

Stir well before use. Apply unthinned using a good quality paint brush or medium pile roller. Apply liberally. Do not exceed the recommended spreading rate.

CLEANING

Return surplus material to container. Wash with clean water immediately after use.

HEALTH AND SAFETY

Please refer to the Safety, Health and Environmental Information on the container. Take special precautions during the surface preparation of pre 1960's painted surfaces as they may contain harmful lead. For further information contact the Crown Customer Relations Team. When preparing all surfaces avoid the inhalation of dust and/or metal particles. Wear a suitable facemask. Material Safety Data Sheets for this and all other Crown Paints products are freely available from the place of purchase or the address below. Store in secure dry conditions inaccessible to children or animals. Containers should be kept closed during storage. Do not empty into drains, watercourses or access routes to septic tanks.



P O Box 37, Crown House, Hollins Road, Darwen, Lancashire, BB3 0BG

Tel: 01254 704951 Fax: 01254 870155

Email: info@crownpaint.co.uk

Website: www.crownpaint.co.uk